

Your TV requires repair.
Please **DO NOT** send accessories
with your television.



Please remove stand, power cord, and any mounts -- **DO NOT** include in shipment.

DO NOT SEND THE REMOTE UNLESS IT IS A PART OF THE PROBLEM.

Be sure to place the television in provided plastic bag before placing in bubble pouch.

Thanks.

The Lifetime Service Center will not be held responsible for any accessories sent in.



1

1 Set box this side up and open taped seam.



3

2 Please remove stand from TV. This box is not designed to hold the stand.

3 Remove the two unattached foam corner cushions from the box.



5

4 Remove plastic bag and place over the television.

5 Place your TV right side up into the two foam corner cushions that are attached in the bottom of the box. [There may be up to three inches of space between the edge of the TV and the inside corner of the cushion, this is OK.]

6 Place the two remaining foam corner cushions, that were previously removed from the box, on the top two corners of the TV.



6

7 Place a copy of your receipt, along with a brief description of the problem [or refer to the form included], inside the box.

8 Re-tape the box and place the provided return shipping label, included in the outside packet, over the original shipping label.

9 Please call Fed-Ex for a pick-up. 1-800-GOFEDEX. (1-800-463-3339)

Call 1-800-447-0092 for assistance if needed. Thank you.